

PRECIP-DIP製品 在庫リスト (2012.02.01 9:00 現在)

※現状弊社にある在庫

1000ヶ以上【 ◎ 】 100ヶ以上1000ヶ未満【 □ 】 100ヶ未満【 △ 】になっております。

※在庫品目及び在庫数は随時変動いたしますので、お問い合わせ時に確認下さい。

また、製品によってはミニマムなどが発生する場合がございます。

詳細については、WEB及びメール・電話などにてお問い合わせ下さい。

※在庫のリストに掲載されていないものもご相談下さい。

TEL:06-6643-3521 FAX:06-6644-1400

お問い合わせはこちらから: <http://www.katohtek.co.jp/inquiry/index.php>

メーカー型番	在庫
01304-93-4710	◎
110-13-306-41-001101	□
110-13-314-41-001101	△
110-13-320-41-001101	△
110-13-324-41-001101	△
110-13-624-41-001101	△
110-13-640-41-001101	△
110-83-064-01-505101	△
110-83-210-41-001101	◎
110-83-304-41-001101	□
110-83-306-41-001101	◎
110-83-308-41-001101	◎
110-83-308-41-105101	□
110-83-308-41-605101	◎
110-83-310-41-001101	□
110-83-314-41-001101	◎
110-83-314-41-605101	◎
110-83-316-41-001101	◎
110-83-316-41-605101	◎
110-83-318-41-001101	◎
110-83-318-41-605101	◎
110-83-320-41-001101	□
110-83-320-41-105101	△
110-83-320-41-605101	◎
110-83-322-41-001101	△
110-83-324-41-001101	◎
110-83-324-41-105101	△
110-83-324-41-605101	◎
110-83-328-41-001101	◎
110-83-422-41-001101	◎
110-83-624-41-605101	◎
110-83-628-41-001101	□
110-83-628-41-105101	□

110-83-628-41-105161	△
110-83-628-41-605101	◎
110-83-632-41-001101	◎
110-83-632-41-105161	□
110-83-632-41-605101	◎
110-83-640-41-001101	◎
110-83-640-41-105101	△
110-83-642-41-001101	◎
110-87-064-01-505101	□
110-87-304-41-001101	◎
110-87-306-41-001101	◎
110-87-308-41-001101	△
110-87-310-41-001101	□
110-87-312-41-001101	◎
110-87-314-41-001101	◎
110-87-316-41-001101	◎
110-87-318-41-001101	◎
110-87-320-41-001101	◎
110-87-322-41-001101	◎
110-87-324-41-001101	◎
110-87-328-41-001101	◎
110-87-420-41-001101	◎
110-87-422-41-001101	◎
110-87-424-41-001101	◎
110-87-428-41-001101	◎
110-87-432-41-001101	◎
110-87-610-41-001101	◎
110-87-624-41-001101	□
110-87-628-41-001101	◎
110-87-632-41-001101	□
110-87-640-41-001101	◎
110-87-640-41-105161	△
110-87-642-41-001101	◎
110-87-648-41-001101	◎
110-91-632-41-105161	◎
110-91-640	◎
110-93-306	□
110-93-628	△
111-83-306-41-001101	□
111-83-308-41-001101	□
111-83-314-41-001101	□
111-87-308-41-001101	□
111-87-312-41-001101	□
111-87-314-41-001101	□
111-87-316-41-001101	△

114-83-432-41-117101	△
114-87-308-41-134161	□
114-87-640-41-117101	□
114-91-628-41-134161	△
115-83-318-41-003101	△
115-83-320-41-003101	□
115-83-328-41-003101	△
115-83-624-41-003101	□
115-83-628-41-003101	△
115-83-640-41-003101	△
115-87-308-41-003101	□
115-87-310-41-003101	□
115-87-320-41-003101	□
115-87-324-41-003101	□
115-87-624-41-003101	△
115-87-628-41-003101	△
115-87-632-41-003101	△
116-83-308-41-006101	△
116-83-310-41-012101	□
116-83-314-41-007101	□
116-83-628-41-003101	△
116-83-632-41-003101	△
116-83-640-41-003101	△
116-93-624-41-007	△
117-83-428-41-005101	◎
117-83-430-41-005101	□
117-83-642-41-005101	□
117-83-648-41-005101	△
117-83-764-41-005101	□
117-87-428-41-005101	◎
117-87-430-41-005101	◎
117-87-432-41-005101	◎
117-87-642-41-005101	□
117-87-652-41-005101	◎
117-87-764-41-005101	◎
122-83-210-41-001101	△
122-83-320-41-001101	△
123-83-314-41-001101	□
123-83-316-41-001101	□
123-83-318-41-001101	△
123-83-640-41-001101	△
123-87-310-41-001101	□
123-87-320-41-001101	□
150-10-316-00-001101	□
150-10-628-00-001101	△

150-10-632-00-001101	□
150-10-642	△
150-80-308-00-001101	△
150-80-314-00-001101	△
150-80-316-00-001101	□
150-80-320-00-001101	□
150-80-632-00-001101	△
151-10-316-00-004101	△
151-10-628-00-004101	△
151-80-640-00-003101	△
160-10-316-00-001101	□
160-80-308-00-001101	△
210-83-310-41-001101	□
210-83-318-41-001101	□
210-83-320-41-001101	◎
210-83-324-41-001101	□
210-83-624-41-001101	□
210-83-628-41-001101	□
210-83-632-41-001101	◎
210-83-640-41-001101	□
210-83-648-41-001101	□
210-87-308-41-001101	□
210-87-632-41-001101	□
210-87-640-41-001101	□
210-91-628	□
210-93-320	△
217-83-764-41-005101	△
299-83-306-11-001101	□
299-83-308-10-001101	△
299-83-310-10-001101	◎
299-83-310-11-001101	□
299-83-314-10-001101	△
299-83-316-11-001101	△
299-83-320-10-001101	△
299-87-312-11-001101	△
299-93-306-11-001	□
310-13-102-41-001101	△
310-13-103-41-001101	△
310-13-104-41-001101	□
310-13-116-41-001101	△
310-13-132-41-001101	△
310-13-164-41-001101	△
310-83-103-41-001101	△
310-83-104-41-205101	△
310-83-106-41-001101	△

310-83-108-41-001101	△
310-83-120-01-640101	△
310-83-120-41-001101	◎
310-83-124-41-001101	△
310-83-132-41-001101	□
310-83-164-41-001101	□
310-83-164-41-205101	△
310-87-102-41-001101	◎
310-87-103-41-001101	△
310-87-104-41-001101	□
310-87-105-41-001101	□
310-87-106-41-001101	△
310-87-107-41-001101	□
310-87-108-41-001101	□
310-87-109-41-001101	△
310-87-110-41-001101	△
310-87-118-41-001101	△
310-87-120-41-001101	△
310-87-131-41-001101	△
310-87-132-41-001101	□
310-87-164-41-001101	□
311-83-164-41-001101	△
311-87-104-41-001101	□
311-87-112-41-001101	□
315-13-120-41-003101	□
315-13-164-41-003101	△
315-83-120-41-003101	△
315-83-164-41-003101	△
315-87-102-41-001101	△
315-87-104-41-001101	△
315-87-104-41-003101	△
315-87-105-41-001101	△
315-87-106-41-001101	△
315-87-108-41-001101	△
315-87-112-41-001101	△
315-87-120-41-003101	□
315-87-164-41-001101	□
315-87-164-41-003101	□
316-83-103-41-001101	△
316-83-103-41-006101	△
316-83-104-41-003101	□
316-83-104-41-006101	△
316-83-104-41-007101	△
316-83-104-41-008101	□
316-83-105-41-003101	△

316-83-105-41-006101	□
316-83-106-41-008101	△
316-83-108-41-006101	△
316-83-109-41-007101	◎
316-83-109-41-008101	△
316-83-110-41-006101	△
316-83-116-41-003101	△
316-83-120-41-003101	△
316-83-120-41-006101	△
316-83-164-41-001101	△
316-83-164-41-003101	□
316-83-164-41-006101	□
316-83-164-41-007101	◎
316-83-164-41-008101	△
316-87-103-41-001101	△
316-87-104-41-018101	△
316-87-109-41-001101	△
316-87-164-41-001101	△
316-87-164-41-002101	△
316-87-164-41-006101	△
316-87-164-41-007101	△
316-87-164-41-009101	△
316-87-164-41-011101	△
316-87-164-41-012101	△
316-87-164-41-018101	△
317-13-121-41-005101	△
317-83-121-41-005101	□
317-83-132-41-005101	□
317-87-132-41-005101	□
322-13-112-41-001101	□
322-13-120-41-001101	△
323-83-104-41-001101	△
323-83-120-41-001101	△
350-10-103-00-006101	△
350-10-104-00-001101	△
350-10-104-00-006101	□
350-10-106-00-001101	△
350-10-108-00-006101	△
350-10-109-00-006101	△
350-10-112-00-001101	△
350-10-114-00-012101	△
350-10-120-00-006101	△
350-10-132	△
350-10-132-00-012101	△
350-10-164-00-001101	△

350-80-103-00-006101	△
350-80-104-00-001101	△
350-80-104-00-006101	△
350-80-107-00-006101	△
350-80-108-00-001101	△
350-80-116-00-001101	△
350-80-116-00-006101	△
350-80-120-00-006101	△
350-80-164-00-001101	△
351-10-104-00-003101	□
351-10-160-00-003101	△
351-10-164-00-005101	△
351-80-102-00-003101	△
351-80-104-00-003101	△
351-80-106-00-003101	△
351-80-112-00-004101	◎
351-80-164-00-003101	□
380-10-120-00-001101	△
399-10-102-10-009101	△
399-10-104-10-009101	◎
399-10-105-10-009101	△
399-10-106-10-009101	△
399-10-108-10-009101	□
399-10-109-10-009101	△
399-10-110-10-009101	△
399-10-112-10-009101	△
399-10-122-10-009101	△
399-10-126-10-009101	△
399-10-132-10-009101	□
399-10-138-10-009101	□
399-10-160-10-009101	△
399-10-164-10-009101	□
399-80-102-10-009101	△
399-80-108-10-009101	△
399-80-110-10-009101	△
399-80-112-10-009101	△
399-80-113-10-009101	△
399-80-116-10-009101	△
399-80-132-10-009101	△
399-80-164-10-009101	□
399-83-102-10-003101	□
399-83-104-10-003101	◎
399-83-124-10-003101	△
399-83-164-10-003101	◎
399-87-102-10-003101	△

399-87-164-10-003101	△
410-83-202-41-001101	△
410-83-204-41-001101	□
410-83-206-41-001101	△
410-83-208-41-001101	□
410-83-210-41-001101	□
410-83-214-41-001101	□
410-83-224-41-001101	□
410-83-264-41-001101	□
410-87-204-41-001101	△
410-87-210-41-001101	△
410-87-222-41-105101	◎
410-87-264-41-001101	△
410-87-272-41-105101	□
415-83-216-41-001101	△
415-83-222-41-001101	△
415-83-224-41-001101	△
415-83-264-41-001101	△
415-87-264-41-001101	△
416-83-214-41-006101	□
416-83-272-41-006101	△
416-87-264-41-006101	△
450-10-208-00-001101	□
450-10-208-00-006101	△
450-10-212-00-006101	△
450-10-216-00-001101	△
450-10-220-00-006101	△
450-10-224-00-001101	△
450-10-232-00-006101	△
450-10-252-00-006101	△
450-10-264-00-001101	□
450-10-272-00-001101	△
450-10-272-00-006101	△
450-80-208-00-001101	□
450-80-208-00-006101	△
450-80-224-00-006101	△
450-80-272-00-001101	△
450-80-272-00-006101	△
451-10-208-00-003101	△
451-10-264-00-003101	△
451-10-264-00-004101	△
499-10-204-10-009101	△
499-10-264-10-009101	□
499-10-272-10-009101	△
499-83-204-10-003101	△

499-83-272-10-003101	△
510-83-068-11-061101	△
510-83-084-11-042101	□
510-83-100-13-063101	△
510-83-132-14-071101	△
510-83-168-17-101101	◎
510-93-133-14-071101	△
511-83-068-11-061101	△
540-88-020-17-400	□
540-88-028-17-400	◎
540-88-028-24-000-1	◎
540-88-032-17-400	□
540-88-032-17-400-2	◎
540-88-032-24-008	□
540-88-044-17-400	◎
540-88-044-17-400-2	◎
540-88-044-24-008	◎
540-88-052-17-400	◎
540-88-052-24-000-1	◎
540-88-068-17-400	◎
540-88-068-17-400-2	◎
540-88-068-24-008	□
540-88-084-17-400	□
540-88-084-17-400-2	□
540-88-084-24-008	□
540-99-028-24-000-1	□
540-99-044-17-400-2	△
540-99-068-17-400-2	△
540-99-068-24-000	△
612-83-324-41-001101	◎
612-83-632-41-001101	□
612-87-324-41-001101	◎
614-83-308-31-012101	△
714-83-102-31-012101	△
714-83-104-31-012101	△
714-83-106-31-012101	□
714-83-107-31-012101	△
714-83-109-31-012101	△
714-83-116-41-001101	△
714-83-120-31-012101	△
714-83-120-31-018101	△
714-83-132-31-012101	△
714-83-160-31-012101	△
714-83-164-31-012101	△
714-87-104-31-018101	□

714-87-107-31-018101	◎
714-87-109-31-018101	□
714-87-110-31-018101	□
714-87-113-31-018101	△
714-87-120-31-018101	△
800-10-002-20-001101	△
800-10-003-20-001101	△
800-10-004-10-001101	◎
800-10-005-10-001101	△
800-10-005-10-002101	△
800-10-006-10-001101	□
800-10-006-10-002101	△
800-10-007-10-001101	□
800-10-008-10-001101	□
800-10-009-10-001101	△
800-10-010-10-001101	△
800-10-011-10-001101	△
800-10-014-10-001101	△
800-10-015-20-001101	△
800-10-018-20-001101	□
800-10-034-10-002101	△
800-10-034-20-001101	△
800-10-064-10-001101	◎
800-10-064-10-002101	□
800-10-064-20-001101	□
800-10-064-30-001101	□
800-80-004-10-002101	□
800-80-007-20-001101	△
800-80-008-10-002101	△
800-80-009-30-001101	△
800-80-014-10-002101	△
800-80-020-10-002101	△
800-80-064-10-001101	□
800-80-064-20-001101	□
800-80-064-30-001101	□
801-83-002-10-001101	□
801-83-002-10-012101	△
801-83-002-10-268101	△
801-83-002-20-001101	△
801-83-003-10-268101	△
801-83-004-10-001101	△
801-83-004-10-268101	△
801-83-004-20-001101	△
801-83-006-10-001101	△
801-83-010-10-001101	□

801-83-010-20-001101	△
801-83-011-10-001101	△
801-83-011-10-012101	□
801-83-011-20-001101	△
801-83-012-10-012101	◎
801-83-012-20-001101	△
801-83-013-20-001101	△
801-83-014-10-001101	△
801-83-016-10-003101	△
801-83-017-10-005101	□
801-83-020-10-001101	△
801-83-022-10-005101	□
801-83-031-10-268101	◎
801-83-032-10-012101	□
801-83-032-10-268101	◎
801-83-036-10-003101	□
801-83-036-10-005101	□
801-83-050-10-001101	□
801-83-050-20-001101	□
801-87-002-10-001101	□
801-87-002-10-012101	□
801-87-003-10-001101	□
801-87-004-10-001101	△
801-87-005-10-001101	△
801-87-006-20-001101	△
801-87-007-10-001101	△
801-87-008-10-001101	□
801-87-008-10-012101	△
801-87-010-10-012101	□
801-87-010-20-001101	△
801-87-011-10-001101	△
801-87-012-10-001101	△
801-87-012-10-003101	△
801-87-012-20-001101	△
801-87-013-10-012101	□
801-87-013-20-001101	△
801-87-014-10-001101	△
801-87-014-10-012101	□
801-87-016-10-012101	□
801-87-018-10-001101	△
801-87-019-10-001101	△
801-87-032-10-001101	△
801-87-032-10-012101	△
801-87-036-10-003101	△
801-87-036-10-005101	□

801-87-040-10-001101	△
801-87-050-10-001101	△
801-87-050-20-001101	□
801-87-050-40-001101	△
801-87-064-20-002101	□
802-10-004-10-001101	◎
802-10-004-10-002101	□
802-10-004-20-001101	□
802-10-004-30-001101	△
802-10-006-10-001101	□
802-10-006-10-002101	△
802-10-006-20-001101	◎
802-10-008-10-001101	◎
802-10-008-10-002101	◎
802-10-008-20-001101	□
802-10-010-10-001101	□
802-10-010-20-001101	□
802-10-010-30-001101	△
802-10-012-10-001101	△
802-10-012-10-002101	□
802-10-012-20-001101	△
802-10-012-30-001101	△
802-10-014-10-001101	□
802-10-014-10-002101	□
802-10-014-30-001101	△
802-10-016-10-001101	□
802-10-016-10-002101	△
802-10-018-10-001101	△
802-10-020-20-001101	△
802-10-022-10-002101	◎
802-10-022-30-001101	△
802-10-024-10-001101	△
802-10-026-10-001101	△
802-10-026-10-002101	□
802-10-030-10-002101	△
802-10-032-10-001101	□
802-10-032-10-002101	△
802-10-032-20-001101	△
802-10-034-10-001101	◎
802-10-034-10-002101	△
802-10-034-20-001101	△
802-10-038-10-001101	□
802-10-038-10-002101	□
802-10-038-20-001101	△
802-10-040-10-001101	□

802-10-046-10-001101	□
802-10-046-10-002101	□
802-10-050-10-002101	◎
802-10-056-10-002101	◎
802-10-064-10-001101	□
802-10-064-10-002101	◎
802-10-072-10-001101	□
802-10-072-10-002101	□
802-10-072-20-001101	□
802-10-072-30-001101	□
802-80-010-10-002101	△
802-80-010-30-001101	△
802-80-012-10-002101	△
802-80-016-30-001101	△
802-80-032-30-001101	△
802-80-072-10-001101	□
802-80-072-10-002101	□
802-80-072-20-001101	□
802-80-072-30-001101	△
803-83-004-10-001101	□
803-83-004-10-005101	△
803-83-004-20-001101	△
803-83-006-10-001101	□
803-83-006-10-002101	◎
803-83-008-10-001101	◎
803-83-008-10-005101	△
803-83-008-10-012101	△
803-83-010-10-012101	△
803-83-012-10-001101	△
803-83-012-10-003101	△
803-83-012-10-012101	△
803-83-014-10-001101	△
803-83-016-10-001101	□
803-83-016-10-003101	△
803-83-016-10-005101	△
803-83-018-10-012101	□
803-83-020-10-001101	△
803-83-020-10-012101	△
803-83-022-20-001101	△
803-83-024-20-001101	△
803-83-026-10-001101	△
803-83-026-10-012101	□
803-83-028-20-001101	△
803-83-028-53-001101	△
803-83-034-10-005101	□

803-83-036-10-001101	△
803-83-044-10-001101	△
803-83-064-10-012101	◎
803-83-072-10-001101	◎
803-83-072-30-002101	□
803-83-100-10-001101	□
803-83-100-10-003101	□
803-83-100-10-005101	△
803-83-100-20-001101	◎
803-83-100-30-001101	□
803-83-100-53-001101	△
803-87-004-10-001101	□
803-87-008-10-001101	△
803-87-008-10-012101	△
803-87-010-10-001101	△
803-87-010-10-012101	□
803-87-012-10-012101	△
803-87-014-10-001101	△
803-87-014-10-005101	□
803-87-016-10-001101	△
803-87-018-10-001101	□
803-87-020-10-001101	△
803-87-024-10-001101	□
803-87-026-10-001101	□
803-87-028-10-012101	△
803-87-034-10-001101	◎
803-87-038-10-001101	□
803-87-046-10-001101	△
803-87-048-20-001101	△
803-87-050-10-001101	△
803-87-064-10-001101	△
803-87-064-10-012101	△
803-87-072-30-002101	□
803-87-086-10-001101	□
803-87-100-10-001101	△
803-87-100-20-001101	△
803-87-100-30-001101	□
803-87-100-53-001101	□
805-83-030-10-012101	△
805-83-096-10-012101	△
805-87-096-10-012101	△
811-S1-064-10-014101	△
811-S1-064-10-015101	△
811-S1-064-10-016101	△
811-S1-064-10-017101	△

811-SS-010-30-001101	△
811-SS-010-30-005101	△
811-SS-010-30-008101	△
813-S1-072-10-014101	△
813-S1-072-10-017101	△
813-SS-020-30-001101	△
830-10-006-10-001101	△
830-10-008-10-001101	□
830-10-010-10-001101	△
830-10-023-10-001101	□
830-10-024-10-001101	◎
830-10-050-10-001101	□
830-80-002-10-001101	△
830-80-006-10-001101	△
830-80-014-10-001101	△
830-80-014-30-001101	△
830-80-050-10-001101	△
830-80-050-20-001101	△
830-80-050-30-001101	□
831-83-002-10-001101	△
831-83-005-10-001101	△
831-83-006-10-242101	△
831-83-007-10-001101	□
831-83-008-10-001101	△
831-83-010-10-242101	△
831-83-015-10-001101	△
831-83-022-10-242101	◎
831-83-023-10-001101	□
831-83-026-10-001101	□
831-83-050-30-001101	□
831-87-003-10-001101	△
831-87-006-10-001101	△
831-87-015-10-001101	△
831-87-016-10-001101	△
831-87-026-10-001101	□
831-87-030-30-001101	△
831-87-050-10-273101	△
831-87-050-30-001101	□
831-91-002-10-001101	◎
832-10-004-10-001101	□
832-10-004-20-001101	◎
832-10-006-10-001101	△
832-10-010-10-001101	△
832-10-012-10-001101	◎
832-10-014-20-001101	△

832-10-016-10-001101	□
832-10-018-10-001101	□
832-10-020-10-001101	□
832-10-022-10-001101	△
832-10-028-10-001101	△
832-10-032-10-001101	◎
832-10-036-10-001101	△
832-10-040-10-001101	◎
832-10-044-30-001101	△
832-10-100-10-001101	△
832-10-100-20-001101	△
832-10-100-30-001101	□
832-80-100-10-001101	□
832-80-100-20-001101	□
832-80-100-30-001101	□
833-83-010-10-245101	△
833-83-012-10-245101	△
833-83-016-10-001101	△
833-83-028-10-001101	△
833-83-032-10-001101	△
833-83-032-20-001101	△
833-83-034-10-001101	□
833-83-040-10-245101	◎
833-83-044-10-245101	△
833-83-044-30-001101	△
833-83-100-20-001101	△
833-83-100-30-001101	□
833-87-032-20-001101	△
833-87-100-10-001101	□
833-87-100-20-001101	△
833-87-100-30-001101	□
850-10-002-10-001101	□
850-10-005-20-001101	□
850-10-010-10-001101	△
850-10-050-10-001101	◎
850-80-002-10-001101	△
850-80-007-10-001101	□
851-83-006-10-001101	△
851-83-042-10-001101	△
852-10-004-10-001101	□
852-10-012-30-051101	△
852-10-014-10-001101	□
852-10-020-10-001101	□
852-10-032-20-001101	△
852-10-040-20-001101	△

852-10-044-30-051101	□
852-10-052-10-001101	△
852-10-068-20-001101	△
852-10-074-20-001101	△
853-83-012-10-001101	□
853-83-012-30-051101	△
853-83-020-10-001101	△
853-83-040-10-001101	□
853-83-040-10-002101	△
853-83-052-20-001101	□
853-87-028-20-001101	△
853-87-040-10-001101	△
853-87-068-20-001101	△
854-10-045-10-001101	△
854-10-135-10-001101	△
855-83-045-20-001101	△
855-83-060-10-001101	△
855-83-066-10-001101	△
855-83-105-10-001101	△
855-83-135-10-001101	△
855-87-135-10-001101	△
890-18-017-10-001101	□
890-18-022-10-001101	□
890-18-040-10-001101	□
890-18-040-10-002101	□
890-18-040-10-003101	□
890-18-040-10-004101	□
890-18-040-20-001101	□
890-18-040-20-002101	□
890-70-040-10-003101	□
890-80-006-20-001101	△
890-80-020-10-001101	△
890-80-020-20-002101	△
890-80-040-10-001101	◎
890-80-040-10-002101	◎
890-80-040-10-003101	□
890-80-040-10-004101	□
890-80-040-20-001101	□
890-80-040-20-002101	□
892-18-010-10-003101	△
892-18-080-10-001101	□
892-18-080-10-002101	□
892-18-080-10-003101	□
892-18-080-10-004101	□
892-18-080-20-001101	□

892-18-080-20-002101	□
892-70-012-10-001101	△
892-80-006-10-001101	△
892-80-010-10-001101	□
892-80-010-10-002101	△
892-80-060-20-002101	△
892-80-080-10-001101	△
892-80-080-10-002101	□
892-80-080-10-003101	□
892-80-080-10-004101	□
892-80-080-20-001101	□
892-80-080-20-002101	□
917-83-104-41-005101	△
917-83-108-41-005101	△
917-83-210-41-005101	△
999-11-110-10	◎